

1. Use otoscope to determine cerumen location.
2. Choose the appropriate curette for the type of patient and cerumen.
3. Place curette into ear canal and remove cerumen.
4. Repeat otoscope exam and determine location of any remaining cerumen.