

Cleanse area around tube and dry thoroughly. Open plastic clamping mechanism; peel off back side of paper in the center area. Apply dressing centering tube into the attachment device. Remove tape from outer edge and secure. Close clamping mechanism over tube.